
# Getting started — SDH Monitor 3.0

# **Connect ground**

Grounding the equipment is important for safety. This equipment must not be operated unless it is grounded. When installing a unit, the connection to protective ground must be made before any other connections are made. When removing a unit, all signal and both power connectors must be removed before disconnecting the protective ground connection. The connector is a  $6.3 \times 0.8$  mm blade connector.

The equipment is intended for use in a location where equipotential bonding has been applied, e.g. telecommunication centre, and which has provision for a permanently connected protective earthing conductor. The protective earthing conductor shall be connected to the protective earthing terminal on the equipment by service personnel.



#### **Connect power**

All sub-modules can be powered simultaneously from nominal 48 V DC via one or both XLR connectors. The plug type is 3-pin female XLR. The connection is polarity-independent.



A sub-module can also be individually powered from PoE. Both Ethernet ports support Power over Ethernet as per IEEE 802.3 §33 "Powered Device" (PD), Class 0 (up to 12,95 W), for Environment A (inter building).

Several power inputs may be used simultaneously for redundancy. Switchover from one source to another is instantaneous. Power is drawn from the source with the highest voltage.

The power consumption is typically 7 W per sub-module.

### **Connect Ethernet**

The port labelled *eth1* is factory-configured to IP address 172.16.1.10, netmask 255.255.0.0.

Ethernet supports Auto-MDIX and Power over Ethernet (PoE).

Shielded ethernet cables must be used.

# Install SFP modules

Insert the SFP (Small Form-factor Pluggable) modules into the SFP sockets, marked P1 and P2. Each SFP socket has a green LED which lights when SDH/SONET framing is recovered (if the interface is enabled).

# Access the HTTP, SSH or API ports

Once the module has booted, approximately 40 seconds after supplying power, the module can be contacted over TCP/IP:

ping: The hardware answers ping requests.


**chirp**: The hardware broadcasts a 'chirp' packet every 120 seconds on UDP port 9. The chirps stop once HTTP, SSH or API contact is made.

**HTTP**: The webserver is at http://172.16.1.10:8888. The default user name is gth and the default password is hemlig.

**SSH**:ssh cli@172.16.1.10. The default password is mFkeDft.

**API**: The Corelatus hardware is normally controlled by a customer-supplied external application. The API reference manual and sample code is available at www.corelatus.com/gth/api/.

#### **Ethernet LEDs**



The module is booting, after power-on or reset. A cold boot takes approximately 40 seconds. This right-hand LED in eth1 can only be yellow during boot, never in any other situation.

eth1 has ethernet link integrity. eth2 is disabled.

eth1 has link integrity. eth2 is enabled but has not found an ethernet link

eth1 has link integrity *and* power-over-ethernet. eth2 is disabled, but has power-over-ethernet.

#### **GPL Notice**

Some software in this product is distributed under the terms of the GNU public licence. www.corelatus.com/gpl contains information on how to order copies.

# **Declaration of Conformity**

Corelatus AB, the manufacturer of the GTH-C3 product, declares under our sole responsibility that the GTH-C3 complies with:

EU Directives 2011/65/EU restriction of hazardous substances (RoHS) 2012/19/EU electrical and electronic equipment waste (WEEE) 2014/30/EU electromagnetic compatibility (EMC) 2014/35/EU electrical equipment safety (LVD)

Safety, Europe IEC/EN 62368-1:2018 IEC CB Test Certificate for CENELEC countries

Safety, USA Recognized Component (CDR) ANSI/UL 62368-1:2019 IEC CB Test Certificate

Safety, Canada CSA C22.2 No.62368-1 IEC CB Test Certificate

EMC, Europe EN 300 386 V2.1.1:2016 Class B

EMC, USA, Canada FCC Part 15(2015) Class B equipment

Telecom Protection, USA ANSI/TIA 968B 2009 TCB Certificate GTHDENANGTH-C3

Telecom Protection, Canada CS03, Issue 8 Terminal Registration No. IC:5157-GTHC3

Johniviller

John Fullemann, Compliance Engineer 9. July 2024

#### **Corelatus AB**

Cylindervägen 12 131 52 Nacka Strand, Sweden www.corelatus.com